

---

## SECTION C

### PUSHBUTTON SWITCHES

---



8020 Series	Snap-Acting Momentary Pushbutton Switches	C-2 thru C-17
8060 Series	Alternate Action and Momentary Pushbutton Switches	C-18 thru C-27
8500 Series	Subminiature Pushbutton Switches	C-28 thru C-31
8600 Series	Microminiature Pushbutton Switches	C-32 thru C-34
E010 Series	Sealed Momentary Pushbutton Switches	C-35 thru C-40
E020 Series	Sealed Snap-Acting Momentary Pushbutton Switches	C-41 thru C-48
EP Series	Sealed Tiny Pushbutton Switches	C-49 thru C-54
EP Series	Sealed Surface Mount Tiny Pushbutton Switches	C-55 thru C-56
GP Series	Sealed Ultra-Miniature Pushbutton Switches	C-57 thru C-59
GP Series	Sealed Ultra-Miniature Surface Mount Pushbutton Switches	C-60 thru C-62
KA Series	Sealed Half-Inch Dome Pushbutton Switches	C-63 thru C-64
KS Series	Pushbutton Key Switches	C-65 thru C-67
KT Series	Sealed Miniature Key Switches	C-68 thru C-69
KT Series	Sealed Surface Mount Miniature Key Switches	C-70 thru C-73
TP Series	Tiny Pushbutton Switches	C-74 thru C-80

---